## Amplifiers and sensor modules

## Main data for Memory relays

Туре	Symbol	Description	Connection <sup>(1)</sup>	Weight kg	Order code
Complete with sub-base PZU-E		With priority reset signal and visula indication With manual override	Ø4 mm Swivel push-in	0,19	PLM-A12 *
Without sub-base For sub-base PZ	U-B12 ↑°	With priority reset signal and visulal indication With manual override		0,14	PLM-A10 *
	× I Iv	Without manual override		0,13	PLM-B10

## Main data for Amplifier relays

Туре	Symbol	Description	Connection <sup>(1)</sup>	Weight kg	Order code
Complete with sub-base PZU-B12		This relay is used to amplify the low pressure signal provided by a fluidic proximity sensor to a useable level With manual override	Ø4 mm Swivel push-in	0,18	PRD-A12 *
Without sub-base For sub-base PZU-		This relay is used to amplify the low pressure signal provided by a fluidic proximity sensor to a useable level With manual override		0,13	PRD-A10 *

## Main data for Sensor relays

Туре	Symbol	Description	Connection <sup>(1)</sup>	Weight kg	Order code
Complete with sub-base PZU-A12		This relay is used to provide a supp to a bleed sensor and to generate a pneumatic signal equal to its supply pressure	oly Ø4 mm Swivel push-in	0,07	PRF-A12 *
Without sub-base For sub-base PZU-A12 or PZU-C12		This relay is used to provide a supp to a bleed sensor and to generate a pneumatic signal equal to its supply pressure	bly	0,03	PRF-A10 *
Indicates stocke	d product.		* ATEX version available (1) For other type of connection		ample : <b>PLM-A12-EX</b> chnical Sales Departmer